



How to update SmartyCam HD firmware

To update SmartyCam firmware through the SD Card, follow this procedure:

- Switch SmartyCam HD off and remove the SD Card from it
- Insert the SD Card into the PC
- Visit the website www.aim-sportline.com – Download Area – Firmware and download the latest firmware release available in the Firmup SmartyCam HD area
- Unzip the downloaded file and copy the contained run file (smarty2_update_v01.XX.XX.run) on the SD Card

Do not copy the run file in a sub-folder

- Move the SD Card from the PC to the SmartyCam HD
- Switch on the SmartyCam HD, by pushing the central and right buttons at the same time
- When the SmartyCam HD is on, release the central button
- When you will see the Linux Penguin on the display, you can also release the right button
- The firmware upgrade is now running
- At the end of this procedure switch on the SmartyCam HD only pushing the central button